# Sewerage System Unit









# PROCESS DIAGRAM AND UNIT ELEMENTS ALLOCATION



The supply of drinking water to a house requires three types of systems: cold water, hot water and sanitation, which includes the removal of waste water and rain water. Drinking water enters the house through the supply pipeline, which is the point where the house system is connected to the mains and wastewaters leave the house through the downpipe, being collected in the sewer pipe and diverted to the municipal sewer line.

The objective of a sanitation system is to facilitate the transport of waters, which may be storm water, wastewater and water from soil moisture.

A sanitation system consists of a network of pipes that collect water and transport it to the municipal sanitation line or sewage system.

Traditionally, waters are classified into three groups: white-waters, those waters with almost no dirt, they come from the rain or the soil moisture; grey-waters, coming from cleaning processes, they contain soaps and their organic matter content is low; and black-waters, they are foul waters with high content of organic matter and come from urinals, toilets or waste disposers.

Sanitation systems work thanks to gravity, pipes are vertical or have reduced slope to facilitate the flow of wastewaters towards the municipal network or septic tank in some cases.

When water is collected below the sewage system a pump, located in a storage well, is required to make the waters rise to the drainage level.

## **GENERAL DESCRIPTION**

With the Sewerage System Unit, "TSID", tests about a wastewater sanitation system can be made and the flow in a sewage system can be observed.

Its design allows the study of the operation and performance of sewage systems. It is specially designed for traing students in the plumbing sector.

A complete sewage system can be observed with the "TSID" unit. The collection of wastewater from a series of sanitary ware and appliances is simulated, since all water supplies must include a downpipe. The unit has 10 toilet tanks at the top, a toilet with tank, a toilet with pressure flush, ventilation pipes and bypass pipes. All of them are controlled by the user with solenoid valves.

The unit is intended for studying pressure and flow in different junctions, cross sections and traps, under different aeration and ventilation conditions.

The water circuit of the unit is closed and consists of a collection tank and a pump to recycle water.

Six manometers are included to study pressure; they indicate the pressure development in the downpipe. Pressure is an essential part to study for the design of sanitation systems, since design errors lead to noise, blockages, etc. A flowmeter is used to measure flow; besides, all the pipes are transparent to allow the flow process visualization.

## **SPECIFICATIONS**

Anodized aluminum frame and panels made of painted steel.

Diagram in the front panel with distribution of the elements similar to the real one.

It includes wheels to facilitate its mobility.

Eleven transparent toilet tanks with solenoid valves controlled by the user:

Six tanks of 10 I.

Four tanks of 20 l.

Tank of 9 I (toilet).

Two toilets with solenoid valves controlled by the user.

Toilet with tank.

Toilet with pressure flush.

All the pipes are made of PMMA to allow the visualization of the process.

Measuring instruments:

Six tube manometers: 1500 mm WC to measure pressure along the downpipe.

Manometer with range: 0.4 - 4 l/h.

Pump:

Power: 0.75 CV.

Flow: 250 l/min.

Head: up to 100 m.

Collection tank:

Volume: 300 l approx.

Electronic console:

Metallic box.

Solenoid valves switches.

Cables and Accessories, for normal operation.

Manuals: This unit is supplied with the following manuals: Required Services, Assembly and Installation, Starting-up, Safety, Maintenance & Practices Manuals.

- 1.- Study of flow and pressure in bypass pipes.
- $\ensuremath{\text{2.-}}$  Study of flow and pressure in sanitary valves and fittings.
- 3.- Study of different drain pipes.
- 4.- Study of an incorrect flow behavior with an error in the pipe sizing.
- 5.- Study of incorrect flow behavior with defective aeration of the pipes.

# **REQUIRED SERVICES**

- Electrical supply: single-phase, 220 V/50 Hz or 110 V/60 Hz.

- 6.- Study of the pressure curve in the downpipe.
- 7.- Study of the flow at a pipe offset.
- 8.- Study of the behavior and the effect of suction at the junctions.

# DIMENSIONS AND WEIGHTS

TSID:				
Unit:				
- Dimensions: 6000 x 800 x 4000 mm approx.				
	(236.22 x 31.49 x 157.48 inches approx.)			
- Weight:	1200 Kg approx.			
	(2645 pounds approx.)			
Electronic console:				
-Dimensions: 300 x 230 x 135 mm approx.				
	(11.81 x 9.05 x 5.31 inches approx.)			
-Weight:	2 Kg approx.			
	(4.4 pounds approx.)			

## Optional



TSID/ICAI. Interactive Computer Aided Instruction Software System:

With no physical connection between unit and computer (PC), this complete software package consists of an Instructor Software (EDIBON Classroom Manager -ECM-SOF) totally integrated with the Student Software (EDIBON Student Labsoft -ESL-SOF). Both are interconnected so that the teacher knows at any moment what is the theoretical and practical knowledge of the students.

Instructor Software

#### - ECM-SOF. EDIBON Classroom Manager (Instructor Software).

ECM-SOF is the application that allows the Instructor to register students, manage and assign tasks for workgroups, create own content to carry out Practical Exercises, choose one of the evaluation methods to check the Student knowledge and monitor the progression related to the planned tasks for individual students, workgroups, units, etc... so the teacher can know in real time the level of understanding of any student in the classroom.

Innovative features:

- User Data Base Management.
- Administration and assignment of Workgroup, Task and Training sessions.
- Creation and Integration of Practical Exercises and Multimedia Resources.
- Custom Design of Evaluation Methods.
- Creation and assignment of Formulas & Equations.
- Equation System Solver Engine.
- Updatable Contents.
- Report generation, User Progression Monitoring and Statistics.



ETTE. EDIBON Training Test & Exam Program Package - Main Screen with Numeric Result Question



ECM-SOF. EDIBON Classroom Manager (Instructor Software) Application Main Screen



ECAL. EDIBON Calculations Program Package - Formula Editor Screen



ERS. EDIBON Results & Statistics Program Package - Student Scores Histogram

### Optional

#### Student Software

### - ESL-SOF. EDIBON Student Labsoft (Student Software).

ESL-SOF is the application addressed to the Students that helps them to understand theoretical concepts by means of practical exercises and to prove their knowledge and progression by performing tests and calculations in addition to Multimedia Resources. Default planned tasks and an Open workgroup are provided by EDIBON to allow the students start working from the first session. Reports and statistics are available to know their progression at any time, as well as explanations for every exercise to reinforce the theoretically acquired technical knowledge.

Innovative features:

- Student Log-In & Self-Registration.
- Existing Tasks checking & Monitoring.
- Default contents & scheduled tasks available to be used from the first session.
- Practical Exercises accomplishment by following the Manual provided by EDIBON.
- Evaluation Methods to prove your knowledge and progression.
- Test self-correction.
- Calculations computing and plotting.
- Equation System Solver Engine.
- User Monitoring Learning & Printable Reports.
- Multimedia-Supported auxiliary resources.

For more information see ICAI catalogue. Click on the following link: www.edibon.com/en/files/expansion/ICAI/catalog



ERS. EDIBON Results & Statistics Program Package - Question Explanation



ESL-SOF. EDIBON Student LabSoft (Student Software) Application Main Screen



EPE. EDIBON Practical Exercise Program Package Main Screen

SMEADSHET				
Computer Court Courter	Plet Table Plet Parchies	Save Table	Open Hely (F1) D.H.	
Determination of the torget and the mechanic power Determination of frictional losses Determination of elesen concumption				
	2-2-	î	Constant Name Value 1 (mm) 42	
7 Relative projection and the second se				
P. Parte and P. Pa	example of the second s	and on the		
Enlarge Picture	100	Tarve	Pre UN	
		10.00		
-				
-				
him				

ECAL. EDIBON Calculations Program Package Main Screen

\* Specifications subject to change without previous notice, due to the convenience of improvement of the product.



C/ Del Agua, 14. Polígono Industrial San José de Valderas. 28918 LEGANÉS. (Madrid). ESPAÑA - SPAIN. Tel.: 34-91-6199363 Fax: 34-91-6198647 E-mail: edibon@edibon.com Web: **www.edibon.com** 

Edition: ED01/17 Date: October/2017 REPRESENTATIVE: